




## Manual - Left to right door sensor fix

1) Entering Setting -> extra setting -> pass words [123456](#) -> Left and right door alignment

2) Click on "Switch front Door"



3) Click "ok" and back to main menu.

4) Reset the Player -> After it please reset the unit .



Thank you